HORÉ-PLAZA
Your supplier of new and used catering equipment

DAILY MAINTENANCE

Hobart hood-type dishwasher

Clean dishes · fewer breakdowns · longer service life

CAUTION

Drain first. Then take out the strainer.

Never remove the strainer (the filter in the bottom of the tank) while there is still water in the tank. Food debris will wash into the pump and the boiler: poor wash results and an expensive breakdown. **Draining:** close the hood, press and hold the ON/OFF button for **3 seconds**. The machine pumps out, rinses itself clean and switches off. Button completely off? Only then take out the strainer.

Hold for 3 seconds
= drain + self-clean

START OF THE DAY

Start-up in 4 steps

1. **Look inside the machine:** are the strainers and the wash and rinse arms properly in place?
   The machine will not start without the strainer.
2. **Open the water tap** and switch on the **main switch** (or plug in).
3. **Check the chemical containers:** enough detergent and rinse aid, suction tube in the liquid.
   Almost empty? Report it, so the machine doesn't run dry mid-service.
4. **Close the hood, press the ON/OFF button briefly.** The machine fills and heats up (a few minutes). Button **fully green** = ready for use.

DURING THE DAY

This is how it washes clean

1. **Scrape off large food scraps** and pre-rinse the dishes with the pre-rinse spray. What doesn't go in, doesn't have to come out.
2. **Load the rack:** plates, glasses and cups face down. Not too full, no stacking.
3. **Rack in, hood down:** the programme starts automatically. The button turns blue and runs back to **green** = done.
   Do not open the hood while the programme is running (hot water and steam).
4. **Hood up, rack out,** let the dishes dry for a moment. Between two washes, leave the hood in the stand-by position (keeps the machine at temperature).

! **Strainer full or washing poorly?** **Drain first** (button 3 s), then empty the strainer, put it back and switch on again.

END OF THE DAY

In this order — always

1. **Last rack out, close the hood.** Press and hold the ON/OFF button for **3 seconds**: the machine drains and cleans itself. Wait until the button is completely off.
2. **Main switch off** (or unplug) and **close the water tap**.
3. **Open the hood. Only now take out the strainers** and rinse them under running water, including the fine strainer.
   Don't let any debris fall into the pump intake.
4. **Wipe down the inside** where the self-clean doesn't reach: inside of the hood, back wall, tank rim. Soft cloth or sponge, mild soapy water.
5. **Put the strainers back** and **leave the hood open**, so the machine dries and airs out.

ONCE A WEEK

- **Wash and rinse arms:** unclip (press the clip), flush through, clear the spray nozzles and clip back in. Only with an empty, drained machine.
- **Run the hygiene programme** as soon as the display asks for it: 2 Hobart cleaning tablets in the empty machine, select the programme, approx. 20 min. The machine switches off by itself afterwards.
- **Wipe the outside and the seals.** White deposits inside the machine? That's limescale: let us know and we'll schedule a descaling.

NEVER DO THIS

- ✕ **Remove the strainer with water in the tank.** Drain first, always.
- ✕ **Chlorine, acid or scouring agents** in or on the machine. They corrode the stainless steel.
- ✕ **Wire brush, steel wool or scouring pad** on the stainless steel. Soft cloth or sponge only.
- ✕ **Pressure washer or hose** on or around the machine. Water in the electronics = breakdown.
- ✕ **Leave the machine full of water overnight** or leave the hood closed. Drain, clean the strainers, hood open.
- ✕ **Use household dishwasher detergent or tablets.** Only products made for professional machines.

Breakdown, question or supplies? Call us. Horé-Plaza • 079-3313997 • info@horeplaza.nl • www.horeplaza.nl

Based on the Hobart PROFI AMX operating instructions. Where this sheet differs from the manual of your machine, the manual prevails. Handelsonderneming Horé-Plaza BV · De Werven 6 · 2731 AZ Benthuizen · The Netherlands